

## INSTALLATION INSTRUCTIONS for PEDI-SINK

- Check included parts in package:
  1. Sink w/drain and overflow and GeniJet™ motor(s).
  2. Air manifold w/elbow.
  3. Air control.
  4. Air switch on/off button.
  5. Air switch control box.
  6. Vinyl tubing ¼ and ½ in
- Locate sink in cabinet, or other location, as required and complete plumbing to suit location.
- Cut two 1 ¼" holes for on/off button and air control knob.
- Attach air switch control box firmly to a solid base.
- Cut a length of ¼" clear vinyl tubing (supplied) and connect on/off button to air switch.
- Attach air manifold to control knob and attach two lengths of ½" vinyl tubing (supplied) from manifold to black elbows on motor. If only one motor is installed, plug extra ports in manifold with plugs supplied.
- Plug electrical cord from motor to outlet in air control box labeled "Motor #1" or "Motor#2"
- If Therapy Light is installed, the adapter should be plugged into the marked outlet.

**\*\* Note\*\*:** The outlet marked "Chair" has constant power and is NOT controlled by the air switch.

The main power from the Air switch control box must be connected to the main 120V supply through a GFCI (Ground Fault Circuit Interrupter)

### Dimensions

